

# Technical information

20<sup>th</sup> November 2020

TI-2020-26

Pages: 2

Issued by: D. Wenner

## DairyPlan (DPView): Installing the Acapela-Version 10 under Windows 10

### Description

An Acapela installation under Windows 10 is one successful if certain specific installation steps are started with the option "Run as Administrator"!



**Please note**

The program must be installed and activated on all the computers (master and client PCs) where speech output is used.

---

### Installing the program (Acapela 10)

Acapela must be installed under Windows 10 as follows:

1. Create the directory: C:\Acapela\_Dairyplan
2. Copy all the folders and files from the installation CD to directory.



**Please note**

The subdirectory "C:\Acapela\_Dairyplan\Data" contains the folders for all the available languages. (~12 GB)

To save memory space, only the necessary language folders need be copied.

---

3. Change on the master PC to the following folder:: C:\Dairyplan



**Please note**

On a network installation with client PCs, the DairyPlan directory connected over the network must be changed.

---

4. Start the program "as administrator": TTS\_SAPI\_51.msi

- Program window appears

5. Follow the installation instructions

- The program will be installed.

6. Close the program window

→ Program installed



## Activating the program

1. Go to the following directory: C:\Acapela\_Dairyplan

2. Start the program "as administrator": RegSapi5.bat

- The program is registered in the operating system

3. Start DPView and open the settings

- The settings dialog will appear

4. Select the "Speech output" tab

5. Activate the speech output function

6. Select language

- If no speech selection menu exists, repeat the activation.

→ Speech output activated

## Related documentation



For more detailed information on this subject, please refer to the instructions:

7160-9001-539